



Installation Guide – Column Casings Complete With 2 Vertical Shadow Gaps

1. Install 2 vertical timber 50mmx50mm battens either side of the steel/concrete structure. Ensure they are set vertically and to the internal diameter of the column casing. (300mm, 400mm, 500mm or 600mm)

Note the casings may flex within 20/30mm of the finished size. This will pull in/open out when the casing is fixed to the timber frame.

2. Notch the top and bottom of each batten to accept the inner collars, to ensure they fit flush with the vertical plane of the timber frame.
3. Screw fix the collars in place at a point which will be concealed by the main casing.

Note – The inner collars maybe oversized depending on which vertical joint is used. These may need trimming back to a slightly smaller diameter than the main casing.

4. Reduce the main casing to the correct ceiling height, allowing for the head and skirting collars.
5. Offer the 2 semi circles up to the timber frame containing the collars and set to the correct height. Strap the casing together and fix to the timber frame through the shadow gaps.
6. Remove the strap with the casing fixed securely in place.